




# PACIFIC

## PISTOL POWDER MEASURE

### OPERATING INSTRUCTIONS



**NOTICE:** Prices and/or specifications are subject to change without notice. Discontinued products may or may not have replacement parts available. Call for availability 800-338-3220.

The Pacific Pistol Powder Measure has been a long time favorite of the cartridge reloader. This measure is a must for the hand gunner who desires speed and accuracy in loading small charges of pistol powder and is equipped with one of the following fixed charge rotors: 2, 2.5, 2.7, 3, 3.5, 4, 4.5, 5 grain bullseye or blank rotors for those who wish to throw a charge other than standard.

1. Fasten measure to bench or table and fill with proper powder.
2. Turn rotor (9-J18) with a steady movement using sufficient force (until you hear it strike on each end of the stroke). This keeps the powder packed tight enough in the rotor (9-J18) cavity to throw uniform charges.
3. Throw a few charges back into the container to "settle" the powder.
4. Because of powder dust, the charge rotor (9-J18) may occasionally stick and not turn freely. If this condition should occur, remove rotor and wipe off with a clean cloth.
5. Always keep measure at least half full of powder.
6. When through using the measure, return remaining powder back into original container.

#### PARTS & PRICE LIST

| PART NO. | DESCRIPTION                        | LIST PRICE |
|----------|------------------------------------|------------|
| 9-J12    | Measure casting complete           | \$ 7.40    |
| 9-J14    | Thumb screw (not shown)            | .20        |
| 9-J15    | Measure tube                       | .80        |
| 9-J16    | Thumb screw ferrule (not shown)    | .10        |
| 9-J17    | Guide screw                        | .40        |
| 9-J18    | Powder rotor                       | 3.00       |
| 9-J19    | Powder measure cap                 | .20        |
| 9-J20    | Powder measure assembly (complete) | \$11.90    |

#### WHEN ORDERING, GIVE COMPLETE DESCRIPTION AND PART NUMBER

Pacific Gun Sight Company cannot assume any liability for damage which may result from the use of the products or information given herein. This is necessary because Pacific Gun Sight Company has no control over the manner in which products or components are used in the reloading operation.



MANUFACTURED IN USA BY

**PACIFIC GUN SIGHT COMPANY**

BOX 4495 • LINCOLN 4, NEBRASKA



All prices and/or specifications subject to change without notice

FORM NO. P-M5-62