

Forend Grip (Chainsaw)

The Chainsaw-style Forend Grip is designed to mount on a Picatinny rail and provides a stable and ergonomic grip with a pistol grip shotgun.



Refer to your firearm's manual for complete safety information. Manuals for Mossberg firearms are available at www.mossberg.com or by contacting the Product Service Center.



Do not use the Forend Grip alone to carry your firearm. The weight of the firearm may allow the action to close and point the firearm in an unsafe direction.



Before use, ensure that the Forend Grip is securely tightened to the Picatinny rail using all three screws provided. The recommended torque of the screws is 30 – 35 inch pounds.



Before use, ensure that the locking lugs on the Forend Grip are engaged into a slot in the Picatinny rail. Failure to engage the locking lugs can result in damage to the forend grip or the Picatinny rail and may result in personal injury.



Before use, ensure that the Forend Grip is securely attached to the forend. The photo below shows a typical position and orientation of the forend grip.

