

KEY CHAIN PEPPER SPRAY



POWERFUL PEPPER SPRAY

Sprays up to 15 feet with 2 million Scoville heat units of law enforcement-strength stopping power.



KEY CHAIN AND VINYL POUCH

Attaches to your keys for easy accessibility.

OTHER RUGER PEPPER SPRAY PRODUCTS:

- Ultra Pepper Spray System
- Armor Case Pepper Spray
- Bear Repellent
- Pro Extreme Speed Release Pepper Spray
- Stealth Pepper Spray System
- Restraint
- Lipstick Pepper Spray
- Lockdown

KEY CHAIN PEPPER SPRAY SYSTEM

Active Ingredient: 10% Oleoresin Capsicum. Strong inflammatory and irritant affects the mucous membranes (eyes, nose, throat) and skin. May cause eyes to close and difficulty breathing. Effects may last up to 45 minutes.

Restriction: Not to be sold to minors or where prohibited by law. Use of this product for other than self defense is a crime that may subject you to punishment under applicable law. Do not carry on any passenger aircraft.

Distributed by: Tornado Personal Defense Systems, Inc.
1465 Slater Road, Ferndale, WA 98248 | 877-460-0939

RKS091



WWW.RUGER.COM/TORNADO



RUGER®

KEY CHAIN PEPPER SPRAY HAVE A PLAN AND ALWAYS BE PREPARED!

KEY CHAIN

Features:

- Spray
- Multiple Carry Options



® Powered by Tornado®



RUGER®

WARNING: READ INSTRUCTIONS CAREFULLY PRIOR TO USE.

Notice: Possession and/or use of pepper spray may be prohibited or regulated in some states or locales. Improper use may result in criminal action, including but not limited to lawsuits, fines, prosecution and even imprisonment. Pepper spray should only be used in cases where you (or someone you are protecting) are in an unavoidable and threatening situation.

Exposure: KEEP OUT OF REACH OF CHILDREN. Severe irritant affects eyes, skin and respiratory areas. In case of exposure, rinse eyes with water. Wash skin thoroughly with soap and water. DO NOT RUB. Do not apply creams, salves or lotions. If symptoms persist after 45 minutes, call a physician.

Caution: Contents under pressure. Keep away from heat. Do not store above 120° F, below 32° F or in direct sunlight. Use caution when activating in windy conditions. Do not puncture or incinerate can. Do not carry on any passenger aircraft.

- 1. Thumb Trigger
- 2. Spray Nozzle
- 3. Lock Tab
- 4. Pepper Spray



Disclaimer of Warranties: To the extent permitted by law, Ruger® and Tornado® shall not be liable for damage, injury, loss, direct or consequential including death arising out of the use of, or inability to use this product. No warranty is expressed or implied. Responsibility for safe and lawful use rests solely with the user.

The Ruger Ultra Pepper Spray System features the same capabilities of the Key Chain Pepper Spray, plus:

 **125 Decibel Alarm** Screams for attention even if you can't.

 **Speed Release** All features activate in less than one second.

 **Bright Strobe Light** Confuses attackers and gives you a chance to get away.

 **Free Belt Clip**

Check Out These Great Ultra Pepper Spray Accessories:



ARMBAND



VEHICLE
DEFENSE



HOME
DEFENSE



REPLACEMENT
HEAD

KEY CHAIN PEPPER SPRAY

1. **WARNING** When practicing do not press the Thumb Trigger.

Before attaching your Key Chain Pepper Spray to your keys, familiarize yourself with the device.

2. Unsnap the leather pouch that contains the pepper spray bottle. The red Lock Tab should be pushed to the side in the lock position so that the Spray Nozzle opening cannot be seen through the notch in front of the device.

Slide the red Lock Tab over so the nozzle opening shows through the notch in the front of the device. This is the unlocked position. Practice moving from locked to unlocked until you are comfortable with this operation.




LOCKED



LOCKED

3. Your Pepper Spray will shoot from the Spray Nozzle at a slightly upward angle. A sweeping spray motion is most effective in ensuring you hit your intended target.

Point the Key Chain Pepper Spray at the aggressor and press down firmly with your thumb on the Thumb Trigger to release the Pepper Spray. (Do not press button while familiarizing yourself with the product).



UNLOCKED

4. Now that you are familiar with the operation of your Key Chain Pepper Spray, place the Lock Tab in the locked position and store the bottle in the snapped leather pouch. Attach your Key Chain Pepper Spray to your keys, bag or other item.

Please ensure that you are familiar with the operation of your Key Chain Pepper Spray, and that you are aware of the applicable laws in your area with respect to the use of this type of product.

