

ULTRA PEPPER SPRAY REPLACEMENT HEAD

OTHER RUGER PEPPER SPRAY PRODUCTS:

- Ultra Pepper Spray System
- Key Chain Pepper Spray
- Bear Repellent
- Pro Extreme Speed Release Pepper Spray
- Stealth Pepper Spray System
- Lipstick Pepper Spray
- Restraint
- Lockdown

CHECK OUT THESE GREAT ULTRA PEPPER SPRAY ACCESSORIES



ARMBAND



VEHICLE DEFENSE



HOME DEFENSE

ULTRA PEPPER SPRAY REPLACEMENT HEAD

Active Ingredient: 10% Oleoresin Capsicum. Strong inflammatory and irritant affects the mucous membranes (eyes, nose, throat) and skin. May cause eyes to close and difficulty breathing. Effects may last up to 45 minutes.

Restriction: Not to be sold to minors or where prohibited by law. Use of this product for other than self defense is a crime that may subject you to punishment under applicable law. Do not carry on any passenger aircraft.

Distributed by: Tornado Personal Defense Systems, Inc.
1465 Slater Road, Ferndale, WA 98248 | 877-460-0939

RRH005



WWW.RUGER.COM/TORNADO



ULTRA PEPPER SPRAY REPLACEMENT HEAD HAVE A PLAN AND ALWAYS BE PREPARED!

ULTRA
REPLACEMENT HEAD



® Powered by Tornado®



RUGER®

WARNING: READ INSTRUCTIONS CAREFULLY PRIOR TO USE.

Notice: Possession and/or use of pepper spray may be prohibited or regulated in some states or locales. Improper use may result in criminal action, including but not limited to lawsuits, fines, prosecution and even imprisonment. Pepper spray should only be used in cases where you (or someone you are protecting) are in an unavoidable and threatening situation.

Exposure: KEEP OUT OF REACH OF CHILDREN. Severe irritant affects eyes, skin and respiratory areas.

In case of exposure, rinse eyes with water. Wash skin thoroughly with soap and water. DO NOT RUB. Do not apply creams, salves or lotions. If symptoms persist after 45 minutes, call a physician.

Caution: Contents under pressure. Keep away from heat. Do not store above 120° F, below 32° F or in direct sunlight. Use caution when activating in windy conditions. Do not puncture or incinerate can. Do not carry on any passenger aircraft.

Please ensure that you are familiar with the operation of your Ultra Pepper Spray System, and that you are aware of the applicable laws in your area with respect to the use of this type of product.

1. Thumb Trigger
2. Spray Nozzle
3. Strobe Light
4. Pepper Spray
5. Finger Lock
6. Actuator Clip
7. Strobe Actuator Tab



Disclaimer of Warranties: To the extent permitted by law, Ruger® and Tornado® shall not be liable for damage, injury, loss, direct or consequential including death arising out of the use of, or inability to use this product. No warranty is expressed or implied. Responsibility for safe and lawful use rests solely with the user.

ULTRA PEPPER SPRAY REPLACEMENT HEAD

To activate the Ultra Pepper Spray System:

- Remove the white Strobe Actuator Tab to activate the strobe of the replacement head (light will now strobe).
- If the original Ultra Pepper Spray head is still in the base, remove and properly discard the original head (visit www.ruger.com/tornado for full instructions). Note that removing the original head will cause the alarm to sound.
- Place the replacement head into the Ultra Pepper Spray System base (both Alarm and Strobe will automatically shut off).
- Slide the clear plastic Safety Door up until it clicks in the closed position.
- Repeat the release and replacement of your Ultra Pepper Spray System to ensure the activation is functioning properly.
- Remove the orange pepper spray Actuator Clip.

Your Ultra Pepper Spray System is now fully activated and in the safe position.



WWW.RUGER.COM/TORNADO